

RADI8

FREESTANDING INFRARED HEATER

Portable 1400W graphene infrared warmth in a slim, silent tower design.

10 YEAR WARRANTY

PORTABLE RADIANT HEAT. SIMPLE CONTROL.

RADI8 freestanding infrared heaters deliver 1400W of direct radiant warmth in a compact tower format. Available in black or white, the range uses a graphene carbon and glass-ceramic heating element with simple mechanical control.

1400W Heating output	<110°C Published surface	8.2 KG Portable design	FLOOR Freestanding use
--------------------------------	---------------------------------------	----------------------------------	----------------------------------

- 01

GRAPHENE HEATING

Glass-ceramic element

Far infrared radiant heat with no fan, visible glow or moving air.
- 02

MECHANICAL CONTROL

Simple knob operation

Straightforward on-unit control for easy everyday operation.
- 03

BUILT-IN SAFETY

Tip-over + overheat

Automatic tip-over shut-off and integrated overheat protection.



MADE TO MOVE

Slim, quiet and easy to reposition between rooms, with a stable freestanding base and no permanent installation required.

Typical applications


Bedrooms • Lounges • Home offices • Hotels • Meeting rooms

FREESTANDING HEATER RANGE

Technical specification

Two colour variants with the same 1400W heating platform.

MODEL / SKU	W	DIMENSIONS (MM)	CONTROL	WEIGHT	SURFACE
Black / FSH1400B	1400	865 x 255 x 90	Mechanical	8.2 kg	<110°C
White / FSH1400W	1400	865 x 255 x 90	Mechanical	8.2 kg	<110°C



CONSTRUCTION

High-grade iron frame and surface with durable rear wire mesh. Graphene carbon + glass-ceramic infrared heating element.

ELECTRICAL

1400W output. 220V stated on the original datasheet; current product listing specifies mechanical knob operation.

PROTECTION

Automatic tip-over shut-off and integrated overheat protection. Stable freestanding base and dense protective mesh.

PORTABLE USE

Freestanding floor heater for indoor rooms. Compact 865 x 255 x 90 mm tower format; no permanent wall or ceiling installation required.

OPERATION, CARE & WARRANTY

Position the heater on a stable, level floor with clear space around the unit. Keep the protective grille unobstructed. Switch off and allow the heater to cool before cleaning. Always follow the supplied operating and safety instructions.

10 YEAR
WARRANTY